



VIDEO TUTORIAL


ⓘ Important!

This replacement procedure can be used for:

MERCEDES-BENZ C-CLASS (W203) C 240 (203.061), MERCEDES-BENZ C-CLASS T-Model (S203) C 240 (203.261), MERCEDES-BENZ CLK (C209) 240 (209.361)

The steps may slightly vary depending on the car design.

REPLACEMENT: ANTI ROLL BAR LINKS – MERCEDES W203. TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #7
- Combination spanner #17
- Drive socket # 16
- Drive socket # 17
- Wheel impact socket #17
- Ratchet wrench
- Wheel chock

Replacement: anti roll bar links – Mercedes W203. AUTODOC recommends:

- Replace the stabiliser links on Mercedes W203 in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- Warning! Shut down the engine before starting any work – Mercedes W203.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Secure the wheels with chocks.

2



Loosen the wheel mounting bolts. Use wheel impact socket #17.

3



Raise the front of the car and secure on supports.

4




Unscrew the wheel bolts.

Replacement: anti roll bar links – Mercedes W203. Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.

5



Remove the wheel.

6




Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.

7



Unscrew the fastener connecting the stabilizer link to the shock strut. Use a drive socket #16. Use a ratchet wrench.

8



Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #16. Use a ratchet wrench.

9



Remove the stabilizer rod.

Replacement: anti roll bar links – Mercedes W203. Tip from AUTODOC:

- Examine stabiliser bushes. Replace them if needed.

10



Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.

11


Install a new rod, tighten the fasteners. Use a combination spanner #17. Use a combination spanner #7. Use a drive socket #17. Use a ratchet wrench.

12


Tighten the fastener connecting the stabilizer link to the shock strut. Use a drive socket #17. Use a torque wrench. Tighten it to 52 Nm torque.

13




Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #17. Use a torque wrench. Tighten it to 52 Nm torque.

14



Treat all joints of the stabiliser link. Use copper grease.

15



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.

16



Clean the brake disk surface. Use a brake cleaner.

AUTODOC recommends:

- Replacement: anti roll bar links – Mercedes W203. After applying the spray, wait a few minutes.

17



Install the wheel.

AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. Mercedes W203

18



Screw in the wheel bolts. Use wheel impact socket #17.

19



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 nm torque.

20



Remove the jacks and chocks.

**DID YOU FIND THESE INSTRUCTIONS
HELPFUL?**

YES

NO



BECOME A MEMBER OF AUTODOC CLUB!

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



AUTODOC APP

Download

 **Google play**

 **App Store**


A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR



BUY SPARE PARTS FOR MERCEDES



ANTI ROLL BAR LINKS: A WIDE SELECTION



CHOOSE CAR PARTS FOR MERCEDES W203



ANTI ROLL BAR LINKS FOR MERCEDES: BUY NOW



ANTI ROLL BAR LINKS FOR MERCEDES W203: THE BEST DEALS & OFFERS



i Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.